

FIGURE 1





FIGURE 2



61	Receiver software
65	Search for signal
66	Decode RDS data
67	Filter RDS groups
68	Format data
64	Output serial data
69	Receiver control

RDS
RDS

117	Main software
118	Enter receiver frequency
119	Enter PI code
120	Enter Capcodes
121	Filter messages
122	Store messages
123	Alarm functions
124	System control

62
63

Block Diagram
Receiver

Figure 3





FIGURE 4

APPENDIX A



FOI 030 220660